

Accessoires	La gamme Digta 7	Digta Station 447 Plus	Digta Soundbox 830	PC
Casques / Écouteurs				
Digta Headphone 565 Jack	•			•
Digta Headphone 565 GBS	o	•	•	
Digta Headphone 565 USB				•
Digta Swingphone 568 Jack	•			•
Digta Swingphone 568 GBS	o	•	•	
Digta Swingphone 568 USB				•
Digta Swingphone 950 Jack	•			•
Digta Earphone 957 Jack	•			•
Digta Earphone 957 GBS	o	•	•	
Digta Earphone 957 USB				•
Pédale de commande				
Pédale 536 GBS	o	•	o	
Pédale 540 USB				•
Station d'accueil				
Digta Station	•			•
Adaptateur Digta W/LAN	•	•		•
Câble USB				
Câble USB mini	•			•
Codes-barres				
Digta Scan 407	•			
Accumulateurs				
Pack d'accus 962	•	•		
Autres				
Digta Card 7	•			•

- compatible
- o raccordement station d'accueil

Accessoires			
			
Digta Headphone 565	Digta Earphone 957	Digta Swingphone 568	Digta Swingphone 950
			
Pédale de commande 536 / 540	Digta Station	Adaptateur Digta W/LAN	Câble mini USB
			
Digta Scan 407	Pack d'accus 962	Digta Card 7	