

Installation instructions for Digta 422 firmware update

Version: V4.0 B 410 from 15.01.2013

i NOTE

Before installing the update, save all dictations from the internal and external memory card onto the PC.

STEP BY STEP

1. Use the USB cable to connect the Digta 422 to the PC and switch it on.
2. Download the update file to the PC.
3. Unpack the ZIP file which has been transferred onto the PC and copy the included file(s) into the SYSTEM folder of the dictation device drive (removable media).
4. Wait until the red recording LED of the Digta 422 stops blinking. Use the "Safely remove hardware" function in the Windows taskbar to disconnect the device from the USB.
5. Disconnect the USB cable from the Digta 422. Confirm the question on the display LOAD UPDATE? with the check button and wait for the loading process to complete.
6. The device is now ready for use..

i FACTORY SETTINGS

After the firmware update, Grundig Business Systems recommends setting the device to the factory settings with the following steps.

1. Use the USB cable to connect the Digta 422 to the PC and switch it on.
2. Open the removable media in the Explorer and copy the GHCONFIG.INI file into the SYSTEM folder and save it on the desktop.
3. Switch off the device, disconnect it from the PC and switch it on.
4. Set the device to factory settings: MENU > SETTINGS > FACTORY SETTINGS, confirm with a check
5. Select the desired language and confirm.
6. Connect the device to the PC. Copy the GHCONFIG.INI file from the desktop back into the SYSTEM folder on the device.
7. Overwrite the existing GHCONFIG.INI file.
8. The device is now ready for use..